


Air conditioner

Installation manual

AM***AN1PCH

- Thank you for purchasing this Samsung air conditioner.
- Before operating this unit, please read this manual carefully and retain it for future reference.



SAMSUNG

Contents

Safety Information	3
Installation Procedure	6
Step 1 Checking and preparing accessories	6
Step 2 Choosing the installation location	6
Step 3 Optional: Insulating the body of the indoor unit	10
Step 4 Installing the indoor unit	10
Step 5 Purging inert gas from the indoor unit	12
Step 6 Cutting and flaring the pipes	12
Step 7 Connecting the assembly pipes to the refrigerant pipes	13
Step 8 Performing the gas leak test	14
Step 9 Insulating the refrigerant pipes	14
Step 10 Installing the drain hose and drain pipe	16
Step 11 Performing the drainage test	17
Step 12 Connecting the power and communication cables	19
Step 13 Optional: Extending the power cable	22
Step 14 Setting the indoor unit addresses and the installation options	25
Performing final check and trial operation	42
Appendix	46
Troubleshooting	46

Safety Information

California Proposition 65 Warning (US)

WARNING

- Cancer and Reproductive Harm - www.P65Warnings.ca.gov.

WARNING

- Hazards or unsafe practices that may result in severe personal injury or death.

CAUTION

- Hazards or unsafe practices that may result in minor personal injury or property damage.
- Carefully follow the precautions listed below because they are essential to guarantee the safety of the equipment.

WARNING

- Always disconnect the air conditioner from the power supply before servicing it or accessing its internal components.
- Verify that installation and testing operations are performed by qualified personnel.
- Verify that the air conditioner is not installed in an easily accessible area.

General information

WARNING

- Carefully read the content of this manual before installing the air conditioner and store the manual in a safe place in order to be able to use it as reference after installation.
- For maximum safety, installers should always carefully read the following warnings.
- Store the operation and installation manual in a safe location and remember to hand it over to the new owner if the air conditioner is sold or transferred.
- This manual explains how to install an indoor unit with a split system with two SAMSUNG units. The use of other types of units with different control systems may damage the units and invalidate the warranty. The manufacturer shall not be responsible for damages arising from the use of non compliant units.

- The manufacturer shall not be responsible for damage originating from unauthorized changes or the improper connection of electric and requirements set forth in the "Operating limits" table, included in the manual, shall immediately invalidate the warranty.
- The air conditioner should be used only for the applications for which it has been designed: the indoor unit is not suitable to be installed in areas used for laundry.
- Do not use the units if damaged. If problems occur, switch the unit off and disconnect it from the power supply.
- In order to prevent electric shocks, fires or injuries, always stop the unit, disable the protection switch and contact SAMSUNG's technical support if the unit produces smoke, if the power cable is hot or damaged or if the unit is very noisy.
- Always remember to inspect the unit, electric connections, refrigerant tubes and protections regularly. These operations should be performed by qualified personnel only.
- The unit contains moving parts, which should always be kept out of the reach of children.
- Do not attempt to repair, move, alter or reinstall the unit. If performed by unauthorized personnel, these operations may cause electric shocks or fires.
- Do not place containers with liquids or other objects on the unit.
- All the materials used for the manufacture and packaging of the air conditioner are recyclable.
- The packing material and exhaust batteries of the remote controller(optional) must be disposed of in accordance with current laws.
- The air conditioner contains a refrigerant that has to be disposed of as special waste. At the end of its life cycle, the air conditioner must be disposed of in authorized centres or returned to the retailer so that it can be disposed of correctly and safely.
- Wear protective equipment (such as safety gloves, goggles, and headgear) during installation and maintenance works. Installation/repair technicians may be injured if protective equipment is not properly equipped.

Safety Information

- This unit is a partial unit air conditioner, complying with partial unit requirements of this International Standard, and must only be connected to other units that have been confirmed as complying to corresponding partial unit requirements of this International Standard.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

Installing the unit

WARNING

IMPORTANT: When installing the unit, always remember to connect first the refrigerant tubes, then the electrical lines.

- Always disassemble the electric lines before the refrigerant tubes.
- Upon receipt, inspect the product to verify that it has not been damaged during transport. If the product appears damaged, DO NOT INSTALL it and immediately report the damage to the carrier or retailer (if the installer or the authorized technician has collected the material from the retailer.)
- After completing the installation, always carry out a functional test and provide the instructions on how to operate the air conditioner to the user.
- Do not use the air conditioner in environments with hazardous substances or close to equipment that release free flames to avoid the occurrence of fires, explosions or injuries.
- Our units must be installed in compliance with the space specifications presented in the installation manual in order to ensure accessibility from both sides and allow repairs or maintenance operations to be carried out.

The unit's components must be accessible and easy to disassemble without endangering people and objects. For this reason, where it is not observed as indicated into the Installation Manual, the cost necessary to reach and repair the unit (in safety, as required by current regulations in force) with slings, trucks, scaffolding or any other means of elevation won't be considered in-warranty and charged to end user.

- If any gas or impurities, except R-410A refrigerant, come into the refrigerant pipe, serious problem may occur and it may cause injury. Use the supplied accessories, specified components and tools for the installation.
 - Do not use the pipe and the installation product used for the R-22 refrigerant.
 - Failure to use the specified components can cause product fall down, water leakage, electrical shock, and fire. (The pipe and flare components used for R-22 refrigerant must not be used)

Power supply line, fuse or circuit breaker

WARNING

- Always make sure that the power supply is compliant with current safety standards. Always install the air conditioner in compliance with current local safety standards.
- Always verify that a suitable grounding connection is available.
- Verify that the voltage and frequency of the power supply comply with the specifications and that the installed power is sufficient to ensure the operation of any other domestic appliance connected to the same electric lines.
- Always verify that the cut-off and protection switches are suitably dimensioned.
- Verify that the air conditioner is connected to the power supply in accordance with the instructions provided in the wiring diagram included in the manual.
- Always verify that electric connections (cable entry, section of leads, protections...) are compliant with the electric specifications and with the instructions provided in the wiring scheme. Always verify that all connections comply with the standards applicable to the installation of air conditioners.
- Devices disconnected from the power supply should be completely disconnected in the condition of overvoltage category.
- Be sure not to perform power cable modification, extension wiring, and multiple wire connection.
 - It may cause electric shock or fire due to poor connection, poor insulation, or current limit override.

-
- When extension wiring is required due to power line damage, refer to Step 13 Optional: Extending the power cable in the installation manual.

CAUTION

Make sure that you earth the cables.

- Do not connect the earth wire to the gas pipe, water pipe, lighting rod or telephone wire. If earthing is not complete, electric shock or fire may occur.

Install the circuit breaker.

- If the circuit breaker is not installed, electric shock or fire may occur.

Make sure that the condensed water dripping from the drain hose runs out properly and safely.

Install the power cable and communication cable of the indoor and outdoor unit at least 1m away from the electric appliance.








Install the indoor unit away from lighting apparatus using the ballast.

- If you use the wireless remote control, reception error may occur due to the ballast of the lighting apparatus.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

Installation Procedure

Step1 Checking and preparing accessories

The following accessories are supplied with the indoor unit. The type and quantity may differ, depending on the specifications.

Dimension template	Drain insulation	
		
Flexible hose	Rubber washer	
		
Installation manual	User manual	
		
Installation template		
		
Bushing bracket		
Small	Medium	Large
		

Step 2 Choosing the installation location

Installation location requirements

- There must be no obstacles near the air inlet and outlet.
- Install the indoor unit on a ceiling that can support its weight.
- Maintain sufficient clearance around the indoor unit.
- Before installing the indoor unit, be sure to check whether the chosen location is well-drained.
- The indoor unit must be installed such that it is beyond public access and is not touchable by users.
- A vibration-resistant location that is not inclined (If the indoor unit is installed on a structure that is not sturdy, it may fall and get damaged or cause injury.)
- Where it is not exposed to direct sunshine.
- Where the air filter can be removed and cleaned easily.

⚠ CAUTION

- As a rule, the unit cannot be installed at a height of less than 8.2ft (2.5m).
- If you install a cassette type indoor unit on the ceiling when temperature is over 80.6°F (27°C) and humidity is over 80%, you must apply an extra 0.39inch (10mm) thick polyethylene insulation or a similar type of insulation to the body of the indoor unit.


Do not install the air conditioner in following places.

- A place with exposure to mineral oil, oil vapour or cooking area where there is spray (If oil adheres to the heat exchanger, performance degradation, spray or condensation scattering may occur. If oil adheres to a plastic component, the component may deform or get damaged. Such issues may result in a system failure or refrigerant leak.)
- The place where corrosive gas such as sulphuric acid gas generates from the vent pipe or air outlet.
- The copper pipe or connection pipe may corrode and refrigerant may leak.
- The place where there is a machine that generates electromagnetic waves. The air conditioner may not operate normally due to control system.
- The place where there is a danger of existing combustible gas, carbon fibre or flammable dust.
- The place where thinner or gasoline is handled. Gas may leak and it may cause fire.

Indoor unit dimensions

Slim 1way cassette (Small)

Unit: inch(mm)



Model		AM005AN1PCH*	AM007AN1PCH*
A	inch(mm)	5.28(134)	
B	inch(mm)	7.09(180)	
Liquid pipe connection	inch(mm)	Ø1/4"(6.35)	
Gas pipe connection	inch(mm)	Ø1/2"(12.7)	
Drain hose connection	inch(mm)	VP20 (outer diameter: Ø1.02(26), inner diameter: Ø0.79(20))	


CAUTION

- If the indoor unit is not leveled, drainage water height measurement may be wrong and it cause water may leak into the room.

Installation Procedure

Slim 1way cassette (Medium)


Unit: inch(mm)



Model		AM009AN1PCH*	AM012AN1PCH*
A	inch(mm)	5.12(130)	
B	inch(mm)	7.05(179)	
Liquid pipe connection	inch(mm)	Ø1/4"(6.35)	
Gas pipe connection	inch(mm)	Ø1/2"(12.7)	
Drain hose connection	inch(mm)	VP20 (outer diameter: Ø1.02(26), inner diameter: Ø0.79(20))	

Slim 1way cassette (Large)


Unit: inch(mm)



Model		AM015/018AN1PCH*	AM024AN1PCH*
A	inch(mm)	5.24(133)	
B	inch(mm)	7.09(180)	
Liquid pipe connection	inch(mm)	Ø1/4"(6.35)	Ø3/8"(9.52)
Gas pipe connection	inch(mm)	Ø1/2"(12.7)	Ø5/8"(15.88)
Drain hose connection	inch(mm)	VP25 (outer diameter: Ø1.26(32), inner diameter: Ø0.98(25))	


Installation Procedure

Spacing requirements



CAUTION

- The indoor unit must be installed according to the specified distances in order to permit accessibility from each side, to guarantee correct operation, maintenance, and repair of the unit. The components of the indoor unit must be reachable and removable under safe conditions for people and the unit.
- Do not carry the unit by holding the refrigerant or drain pipes to avoid product damage.
- Carry the unit by holding the hanger plates located on the corners of the unit.



Step 3 Optional: Insulating the body of the indoor unit


Cut openings in the insulation for unit refrigerant and drain pipes.

Insulate the end of the pipe and some curved area by using separate insulator.

Step 4 Installing the indoor unit


When deciding on the location of the air conditioner the following restrictions must be taken into account.

- 1 Place the pattern sheet on the ceiling at the location where you want to install the indoor unit.




NOTE

- Since the diagram is made of paper, it may shrink or stretch slightly due to temperature or humidity. For this reason, before drilling the holes, be sure to maintain the correct dimensions between the markings.
- 2 Insert bolt anchors, use existing ceiling supports or construct a suitable support as shown in figure.



- 3 Install the suspension bolts, depending on the ceiling type.




⚠ CAUTION


- Make sure that the ceiling is strong enough to support the weight of the indoor unit. Before hanging the unit, test the strength of each attached suspension bolt.
 - If the length of the suspension bolt is more than 4.92ft(1.5m), vibration prevention is recommended.
- 4 Screw eight nuts and washers to the suspension bolts, making space for hanging the indoor unit.

⚠ CAUTION

- You must install all of the suspension rods.
 - It is important to leave sufficient space in the false ceiling to allow access for maintenance or repairs to the drainage pipe connection, the refrigerant pipe connection, or to remove the unit if necessary.
- 5 Hang the indoor unit to the suspension bolts between two nuts. Screw the nuts to suspend the unit.



- 6 Check the level of the indoor unit by using a Level.
 - A tilt of the indoor unit may cause malfunction of a built-in float switch and water leaks.



- 7 Adjust the unit to the appropriate position, taking into account the installation area for the front panel.
 - Place the pattern sheet on the indoor unit.
 - Adjust the space between the ceiling and the indoor unit by using a Tape measure.
 - Fix the indoor unit securely after adjusting the level of the unit by using a level.
 - Remove the pattern sheet and install the front panel.

When the installation template is made of paper


Unit: inch(mm)

Slim 1way cassette (Small, WindFree) 	Slim 1way cassette (Small)
Slim 1way cassette (Medium, WindFree) 	Slim 1way cassette (Medium)
Slim 1way cassette (Large, WindFree) 	Slim 1way cassette (Large)

Installation Procedure

When the installation template is made of plastic


Unit : inch(mm)



Step 5 Purging inert gas from the indoor unit

The indoor unit comes with nitrogen gas (inert gas) charged at the factory. Therefore, all inert gas must be purged before connecting the refrigerant pipes.

Unscrew the pinch pipe at the end of each refrigerant pipe.




NOTE


- To prevent dirt or foreign objects from getting into the pipes during installation, do not remove the pinch pipe completely until you are ready to connect the piping.

Step 6 Cutting and flaring the pipes

- Make sure that you have the required tools available: pipe cutter, reamer, flaring tool, and pipe holder.
- If you wish to shorten the pipes, cut them with a pipe cutter, ensuring that the cut edge remains at a 90° angle to the side of the pipe. Refer to the illustrations below for examples of edges cut correctly and incorrectly.




- To prevent any gas from leaking out, remove all burrs at the cut edge of the pipe, using a reamer.
- Slide the flare nuts onto the pipes, then flare each pipe.



Outer Diameter (D)		Depth (A)		Flare dimension (L)	
mm	inch	mm	inch	mm	inch
Ø6.35	1/4	1.3	0.051	8.7 to 9.1	0.34 to 0.36
Ø9.52	3/8	1.8	0.071	12.8 to 13.2	0.50 to 0.52
Ø12.70	1/2	2.0	0.079	16.2 to 16.6	0.64 to 0.65
Ø15.88	5/8	2.2	0.087	19.3 to 19.7	0.76 to 0.78
Ø19.05	3/4	2.2	0.087	23.6 to 24.0	0.93 to 0.94


- Check that the flaring is correct, referring to the illustrations below for examples of incorrect flaring.



Step 7 Connecting the assembly pipes to the refrigerant pipes

There are two refrigerant pipes of different diameters :

- A smaller one for the liquid refrigerant.
 - A larger one for the gas refrigerant. The inside of copper pipe must be clean and has no dust.
- 1 Remove the two pinch pipes and connect the field refrigerant pipes. Tighten the flare nuts, first manually and then with a torque wrench and a backup wrench applying the following torque.



Outer Diameter (mm)		Torque	
mm	inch	N·m	lbf.ft
Ø6.35	1/4	14 to 18	10.3 to 13.3
Ø9.52	3/8	34 to 42	25.1 to 31.0
Ø12.70	1/2	49 to 61	36.1 to 45.0
Ø15.88	5/8	68 to 82	50.2 to 60.5
Ø19.05	3/4	100 to 120	73.8 to 88.5

(1N·m=10kgf·cm)

NOTE

- If the pipes must be shortened, see **Step 6 Cutting and flaring the pipes** on page 12.
- 2 Be sure to use an insulator thick enough to cover the refrigerant pipes to improve the efficiency of the unit and to prevent condensate water formation on the outside of the pipes falling onto the floor.
- 3 Cut off any excess foam insulation.
- 4 Make sure that there are no cracks or waves on the bent area.
- 5 It is necessary to double the insulation thickness (0.39inch or more) to prevent condensation on the insulator when the installed area is warm and humid.
- 6 Do not use joints or extensions for the pipes connecting the indoor and outdoor units. The only permitted connections are those for which the units are designed.

CAUTION

- Connect the indoor and outdoor units using pipes with flared connections (not supplied). For the lines, use insulated, unwelded, degreased and deoxidized copper pipe (Cu DHP type to ISO 1337 or UNI EN 12735-1), suitable for operating pressures of at least 4.2MPa (609.2 psig) and for a burst pressure of at least 20.7MPa (3002.3 psig). Copper pipe for hydro-sanitary applications is completely unsuitable.
- For sizing and limits (height difference, line length, max. bends, refrigerant charge, etc.) see the outdoor unit installation manual.
- All refrigerant connection must be accessible, in order to permit either unit maintenance or removing it completely.
- If the pipes require brazing, make sure that oxygen free nitrogen (OFN) is flowing through the system.
- Nitrogen blowing pressure range is 0.02 to 0.05 MPa (2.9 to 7.3 psig).


Installation Procedure

Step 8 Performing the gas leak test

To identify potential gas leaks on the indoor unit, inspect the connection area of each refrigerant pipe using a leak detector for R-410A.

Before creating a vacuum and adding refrigerant, pressurize the whole system with nitrogen using a cylinder with a pressure reducer at a pressure above 4.1MPa (594.7 PSI) in order to detect leaks on the refrigerant fittings.

Made vacuum for 15 minutes and pressurizing system with nitrogen.



Step 9 Insulating the refrigerant pipes

Once you have checked that there are no leaks in the system, you can insulate the piping and hose.

1 Select the insulation of the refrigerant pipe.

- Insulate the gas side and liquid side pipe, noting the insulation thickness that must differ according to the pipe size.
- Standard: Less than an indoor temperature of 86°F (30°C), with humidity at 85%. If installing in a high humidity environment, use one grade thicker insulator by referring to the table below. If installing in an unfavourable environment, use thicker one.
- The heat-resistance temperature of the insulator must be more than 248°F (120°C).

Pipe	Outer diameter		Insulation Type (Cooling, Heating)				Remarks
			General [86°F(30°C), 85%]		High humidity [86°F(30°C), over 85%]		
			EPDM, NBR				
	mm	inch	mm	inch	mm	inch	
Liquid pipe	6.35~9.52	1/4~3/8	9	3/8	9	3/8	Heating resisting temperature over 248°F(120°C)
	12.7~50.80	1/2~2	13	1/2	13	1/2	
Gas pipe	6.35	1/4	13	1/2	19	3/4	
	9.52~25.4	3/8~1	19	3/4	25	1	
	28.58~44.45	11/8~13/4	19	3/4	32	11/4	
	50.8	2	25	1	38	11/2	

- When installing insulation in the places and conditions below, use the same insulation that is used for high humidity conditions.

<Geological condition>

High humidity locations such as shorelines, hot springs, lake or riversides, and ridges (when part of the building is covered by earth and sand)

<Operation purpose condition>


Restaurant ceiling, sauna, swimming pool etc.

<Building construction condition>

Ceilings frequently exposed to moisture and cooling are not covered. For example, pipes installed at a corridor of a dormitory and studio or near an exit that opens and closes frequently.

Places (where the pipes are installed) that are highly humid due to a lack of ventilation.


- Refrigerant pipe before EEV kit and MCU or without EEV kit and MCU
 - You can contact the gas side and liquid side pipes but the pipes should not be pressed.
 - When contacting the gas side and liquid side pipe, use 1 grade thicker insulator.
 - Refrigerant pipe after EEV kit and MCU
 - Install the gas side and liquid side pipes, leave 0.39inch (10mm) of space.
 - When contacting the gas side and liquid side pipe, use 1 grade thicker insulator.
- 2 To avoid condensation problems, place Acrylonitrile Butadien Rubber separately around each refrigerant pipe.



NOTE


- Always make the seam of pipes face upwards.

- 3 Wind insulating tape around the pipes and drain hose avoiding compressing the insulation too much.
- 4 Finish wrapping insulating tape around the rest of the pipes leading to the outdoor unit.
- 5 The pipes connecting the indoor unit with the outdoor unit must be fixed to the wall with suitable hangers or ducts.



CAUTION

- Must fit tightly against body without any gap.
- Use waterproof adhesives to prevent moisture from penetrating the connection part between the insulation and the indoor unit.
- Wind the refrigerant pipe with insulation tape if it is exposed to outside sunlight.
- Install the refrigerant pipe respecting that the insulation does not get thinner on the bent part or hanger of pipe.
- Add the additional insulation if the insulation plate gets thinner.



- Must fit tightly against body without any gap.
- All refrigerant connection must be accessible, in order to permit either unit maintenance or removal.

Charging additional refrigerant


The amount of additional refrigerant for each indoor unit.

Model	Charging additional refrigerant (kg)
AM005AN1PCH*	0.15
AM007AN1PCH*	0.15
AM009AN1PCH*	0.25
AM012AN1PCH*	0.25
AM015AN1PCH*	0.32
AM018AN1PCH*	0.32
AM024AN1PCH*	0.32


Installation Procedure

Step 10 Installing the drain hose and drain pipe


- 1 Fix the flexible hose to the drain pipe.
 - The connection port of the flexible hose and PVC drain pipe must be fixed with PVC adhesives. Check out that the connected part doesn't leak.



- 2 Connect the flexible hose to the drain hose port.
 - Make sure that a rubber ring is installed on the drain hose port.
 - The drain hose port location differs depending on the unit types.



- 3 Cover the flexible hose with the provided insulation.
 - Do not give the hose an upward gradient beyond the connection port. This will cause water to flow backwards when the unit is stopped, resulting in water leaks.




- 4 Field installed drain lines should be kept as short as possible.
- 5 Insulate the whole drain pipe inside the building (field supply).
The whole drain pipe must be insulated with 0.2 inch (5mm) (or more) insulation to prevent condensation.


⚠ CAUTION

Check that the indoor unit is level with the ceiling by using by using a level.


- If the slope of the drain pipe is less than 1/100, be sure to install an air vent at the top of each indoor unit to prevent water from flowing back to the unit.
 - If the slope of the drain pipe is 1/100 or more and it is free from backward flow to the indoor unit, you are not required to install an air vent.




- If it is necessary to increase the height of the drain pipe, install a horizontal drain pipe that is 12 inches or less (305 mm) from the drain hose port. If it is raised higher than 19.69 inch (500 mm), there may be water leaks.




- Do not give the hose an upward gradient beyond the connection port. This will cause water to flow backwards when the unit is stopped, resulting in water leaks.




- Do not apply force to the piping on the unit side when connecting the drain hose. The hose should not be allowed to hang loose from its connection to the unit. Fasten the hose to a wall, frame or other support as close to the unit as possible.




- Install horizontally.



- Max. allowable axis gap




- Max. allowable bending angle



NOTE


- If a concentrated drain pipe is installed, refer to the figure below.



- If 3 or more units are installed, install a main air vent in front of the farthest indoor unit from the main drain pipe.
- To prevent water from flowing back to indoor units, install an individual air vent at the top of each indoor unit.
 - The air vents should be T or 7 shaped to prevent dust or foreign substances from entering.
 - You may not need to install an air vent if the horizontal drain pipe has a proper slope.

Step11 Performing the drainage test

- Do a leak test at the connection part of the flexible hose and the drain pipe:
 - Connect a general hose to the connection part of the flexible hose of the indoor unit, and pour in some water.



Installation Procedure


- b After pouring some water, reassemble the rubber cap on the connection part of a flexible hose of the indoor unit and firmly tighten it with a band to prevent leakage.
- c Check the leak test at the part where the adhesive for the flexible hose and the drain pipe is used.

⚠ CAUTION

- The leak test must be performed for at least 24 hours.

2 Check the condensed water drainage:

- a Pour about 1ℓ of water into the indoor unit drain pan as shown in the picture.



- b When the electric cable connection is completed
 - Turn on the indoor unit and outdoor unit.
 - Operate in the Cool mode.

⚠ CAUTION

- Only in the Cool mode, you can check the correct operation of the drain pump.

When the electric cable connection has not been completed

- Remove the control box cover of the indoor unit.
- Connect the power supply to the L and N terminals.
- Reassemble the control box cover and turn on the indoor unit.


⚠ CAUTION

- When the float switch is not detected due to insufficient water on the drain pan, the drain pump will not work.
- If the power supply is directly connected to the L and N terminals, communication error message might appear.
- After completing the drainage check, turn the unit off and disconnect the power supply.

- Reassemble the control box cover.
- c Check whether the drain pump works correctly.
- d Check whether the drainage is performing correctly at the end of the drain pipe.
- e Check for leakage at the drain pipe and drain pipe connection part.
- f When leakage occurs, check whether the indoor unit is level and check the drain hose connection part, drainpipe connection part and drain pump connection.
- g When the drainage check is completed and the condensed water remains on the drain pan, remove the water.

Bushing bracket installation

When connecting the power supply wire conduit, the supplied bracket must be installed as shown in the picture below.



NOTE

- Please follow national and local electrical codes. Additional electrical connection components may be required.



Step 12 Connecting the power and communication cables

Power and communication cable connection

- Before wiring work, you must turn off all power source.
- Connect the power and communication cable among the units within maximum length to set the voltage drop under 10%.
- If multiple indoor units are connected to a single circuit breaker (ELCB, MCCB, ELB), the circuit breaker size must be sized based on local and national electric codes.
- If a wired controller is required, connect F3/F4 from the indoor unit to the F3/F4 terminals on the wired controller.
- Tighten the electric wires with a proper tool within the torque limit to connect and fix them firmly, and then organize the wires to prevent outside pressure being exerted on the covers and other parts. Failure to do so may result in overheating, electric shock, and fire.
- To protect the product from water and possible shock, you should keep the power and the communication cables of the indoor and outdoor units in the iron pipe.
- Connect the power cable to the auxiliary circuit breaker (ELCB, MCCB, ELB).
- Keep distances of 1.97inch (50mm) or more between power cable and communication cables.
- Power supply cords of parts of appliances for outdoor use shall not be lighter than polychloroprene sheathed flexible cord. (Code designation IEC:60245 IEC 57 / CENELEC: H05RN-F or IEC:60245 IEC 66 / CENELEC: H07RN-F)
- Screws on terminal block must not be unscrewed with the torque less than 0.87 lbf.ft (12 kgf•cm).
- When installing the indoor unit in a computer room, use the double shielded (tape aluminum / polyester braid + copper) cable of FROHH2R type.

	Tightening torque	
	N·m	lbf.ft
M3.5	0.8 to 1.2	0.59 to 0.89
M4	1.2 to 1.8	0.89 to 1.1


(1N·m=10kgf·cm)



Installation Procedure

Selecting the crimping terminal lug


- 1 Select the crimping terminal lug based on the normal dimension of the power cable.
- 2 Cover the connection part of the power cable and crimping terminal lug to insulate it.



Nominal dimensions for cable [inch ² (mm ²)]		0.0023 (1.5)		0.0039 (2.5)		0.0062 (4)
Nominal dimensions for screw [inch(mm)]		0.157 (4)	0.157 (4)	0.157 (4)	0.157 (4)	0.157 (4)
B	Standard dimension [inch(mm)]	0.260 (6.6)	0.315 (8)	0.260 (6.6)	0.335 (8.5)	0.374 (9.5)
	Allowance [inch(mm)]	± 0.008 (0.2)		± 0.008 (0.2)		± 0.008 (0.2)
D	Standard dimension [inch(mm)]	0.134 (3.4)		0.165 (4.2)		0.220 (5.6)
	Allowance [inch(mm)]	+0.012 (0.3) -0.008 (0.2)		+0.012 (0.3) -0.008 (0.2)		+0.012 (0.3) -0.008 (0.2)
d1	Standard dimension [inch(mm)]	0.067 (1.7)		0.091 (2.3)		0.134 (3.4)
	Allowance [inch(mm)]	± 0.008 (0.2)		± 0.008 (0.2)		± 0.008 (0.2)
E	Min. [inch(mm)]	0.161 (4.1)		0.236 (6)		0.236 (6)
F	Min. [inch(mm)]	0.236 (6)		0.236 (6)		0.236 (6)
L	Max. [inch(mm)]	0.630 (16)		0.689 (17.5)		0.787 (20)
d2	Standard dimension [inch(mm)]	0.169 (4.3)		0.169 (4.3)		0.169 (4.3)
	Allowance [inch(mm)]	+0.008 (0.2) 0 (0)		+0.008 (0.2) 0 (0)		+0.008 (0.2) 0 (0)
t	Min. [inch(mm)]	0.028 (0.7)		0.031 (0.8)		0.035 (0.9)

Specifications of the terminal blocks

Unit: inch(mm)



Power supply (single phase)	MCCB	ELB
Min : 187V Max : 253V	XA	XA, 30 mA 0.1 s
Power cable	Earth cable	Communication cable
0.004 inch ² (2.5 mm ²)		0.0011~0.0023 inch ² (0.75~1.5 mm ²)

Decide the power cable specification and maximum length by formula 2.

- 1 Decide the capacity of ELB and MCCB by below formula.

The capacity of ELB, MCCB X[A] = 1.25 X 1.1 X Σ Ai

NOTE

- X : The capacity of ELB, MCCB
- Σ Ai : Sum of rating currents of each indoor unit.

Rated currents

Model	Rating current(A)
AM005AN1PCH*	0.14
AM007AN1PCH*	0.15
AM009AN1PCH*	0.23
AM012AN1PCH*	0.25
AM015AN1PCH*	0.26
AM018AN1PCH*	0.28
AM024AN1PCH*	0.40

- 2 Decide the power cable specification and maximum length within 10% voltage drop among indoor units.


$$\sum_{k=1}^n \left(\frac{\text{Coef} \times 35.6 \times L_k}{1000 \times A_k} \times i_k \right) < 10\% \text{ of input voltage[V]}$$

NOTE

- Coef: 1.55
- Lk: Distance among each indoor unit[m], Ak: Power cable specification[mm²(inch²)]
- ik: Running current of each unit[A]

Example of Installation

Total power cable length L = 328.08ft(100m), Initial pull-in current = 10[A], Running current of each units = 1[A], Total 10 indoor units were installed



- Apply following equation.

$$\sum_{k=1}^n \left(\frac{\text{Coef} \times 35.6 \times L_k \times i_k}{1000 \times A_k} \right) < 10\% \text{ of input voltage[V]}$$

Installation Procedure

- Calculation
 - Installing with 1 sort wire.

$$\begin{array}{c}
 \begin{array}{|c|c|c|c|c|} \hline 0.004 \text{ [inch}^2\text{]} & 0.004 \text{ [inch}^2\text{]} & \cdots & 0.004 \text{ [inch}^2\text{]} & \cdots \\ \hline (2.5\text{mm}^2) & (2.5\text{mm}^2) & & (2.5\text{mm}^2) & \\ \hline \end{array} \\
 \begin{array}{|c|c|c|c|c|} \hline -2.2 \text{ [V]} & -2.0 \text{ [V]} & & & \\ \hline \end{array} \\
 \hline
 \end{array}
 \rightarrow \text{Within 187V to 253V}$$

220 [V]
 $208.8 \text{ [V]} : \text{Applicable}$
 $-(2.2+2.0+1.8+1.5+1.3+1.1+0.9+0.7+0.4+0.2)=-11.2 \text{ [V]}$

- Installing with 2 different sort wire.

$$\begin{array}{c}
 \begin{array}{|c|c|c|c|c|} \hline 0.006 \text{ [inch}^2\text{]} & 0.006 \text{ [inch}^2\text{]} & \cdots & 0.004 \text{ [inch}^2\text{]} & \cdots \\ \hline (4.0\text{mm}^2) & (4.0\text{mm}^2) & & (2.5\text{mm}^2) & \\ \hline \end{array} \\
 \begin{array}{|c|c|c|c|c|} \hline -1.4 \text{ [V]} & -1.2 \text{ [V]} & & & \\ \hline \end{array} \\
 \hline
 \end{array}
 \rightarrow \text{Within 187V to 253V}$$

220 [V]
 $209.5 \text{ [V]} : \text{Applicable}$
 $-(1.4+1.2+1.8+1.5+1.3+1.1+0.9+0.7+0.4+0.2)=-10.5 \text{ [V]}$

⚠ CAUTION

- Select the power cable in accordance with relevant local and national codes.
- Wire size must comply with local and national code.
- You should connect the power cable into the power cable terminal and fasten it with a clamp.
- The unbalanced power must be maintained within 10% of supply rating among whole indoor units.
- If the power is unbalanced greatly, it may shorten the life of the condenser. If the unbalanced power is exceeded over 10% of supply rating, the indoor unit is protected, stopped and the error mode indicates
- Connect the power cable to the auxiliary circuit breaker. A 2 pole disconnection from the power supply must be incorporated in the field wiring 0.12 inch (3mm).
- Depending on the installation location, power cables should be installed in a protective conduit in accordance with local and national codes.
- Maximum length of power cables are decided within 10% of power drop. If it exceeds, you must consider another power supplying method.
- If multiple indoor units are connected to a single circuit breaker (ELCB, MCCB, ELB), the circuit breaker size must be sized based on local and national electric codes.
- Use round pressure terminal for connections to the power terminal block.


- For wiring, use the designated power cable and connect it firmly, then secure to prevent outside pressure being exerted on the terminal board.
- Use an appropriate screwdriver for tightening the terminal screws. A screwdriver with a small head will strip the head and make proper tightening impossible.
- Over-tightening the terminal screws may break them.

Step 13 Optional: Extending the power cable

- 1 Prepare the following tools.

Tools	Spec	Shape
Crimping pliers	MH-14	
Connection sleeve [inch(mm)]	0.79xØ0.26 (20xØ6.5) (HxOD)	
Insulation tape [inch(mm)]	Width 0.75 inch (19 mm)	
Contraction tube [inch(mm)]	2.76xØ0.31 (70xØ8.0) (LxOD)	

- 2 As shown in the figure, peel off the shields from the rubber and wire of the power cable.
 - Peel off 0.79 inch (20 mm) of cable shields from the pre-installed tube.




⚠ CAUTION

- For information about the power cable specifications for indoor and outdoor units, refer to the STEP12.
- After peeling off cable wires from the pre-installed tube, insert a contraction tube.

3 Insert both sides of core wire of the power cable into the connection sleeve.

- Method 1:** Push the core wire into the sleeve from both sides.
- Method 2:** Twist the wire cores together and push it into the sleeve.




⚠ CAUTION


- If cable wires are connected without using connecting sleeves, their contact area becomes reduced, or corrosion develops on the outer surfaces of the wires (copper wires) over a long time. This may cause an increase of resistance (reduction of passing current) and consequently may result in a fire.

4 Using a crimping tool, compress the two points and flip it over and compress another two points in the same location.


- The compression dimension should be 8.0.




- After compressing it, pull both sides of the wire to make sure it is firmly pressed.




5 Apply heat to the contraction tube to contract it.



6 Wrap it with the insulation tape twice or more and position your contraction tube in the middle of the insulation tape.



7 After tube contraction work is completed, wrap it with the insulation tape to finish. Three or more layers of insulation are required.




⚠ CAUTION


- Make sure that the connection parts are not exposed to outside.
- Be sure to use insulation tape and a contraction tube made of approved reinforced insulating materials that have the same level of withstand voltage with the power cable. (Comply with the local regulations on extensions.)

⚠ WARNING

- In case of extending the electric wire, please DO NOT use a round-shaped Pressing socket.
 - Incomplete wire connections can cause electric shock or a fire.




Installation Procedure



Step 14 Setting the indoor unit addresses and the installation options


You cannot set the indoor unit address and the installation options at the same time. Set the address and option settings separately.

Common steps for setting address and options



NOTE


- The remote control display and buttons may vary depending on the model.
- Enter option setting mode:
 - Remove the batteries from the remote.
 - While holding down the Temp up (+) and Temp down (-) buttons simultaneously, insert the batteries into the remote control.
 - The controller will display "On", "Auto", and "00" when option setting mode is entered successfully.



2 Set the option values.

CAUTION

- The total number of available options are 24: SEG1 to SEG24.
- Because SEG1, SEG7, SEG13, and SEG19 are the page options used by the previous remote control models, the modes to set values for these options are skipped automatically.
- Set a 2-digit value for each option pair in the following order: SEG2 and SEG3 → SEG4 and SEG5 → SEG6 and SEG8 and SEG9 → SEG10 and SEG11 and SEG12 → SEG14 and SEG15 → SEG16 and SEG17 → SEG18 and SEG20 → SEG21 and SEG22 → SEG23 and SEG24









SEG1	SEG2	SEG3	SEG4	SEG5	SEG6
0	X	X	X	X	X
SEG7	SEG8	SEG9	SEG10	SEG11	SEG12
1	X	X	X	X	X
SEG13	SEG14	SEG15	SEG16	SEG17	SEG18
2	X	X	X	X	X
SEG19	SEG20	SEG21	SEG22	SEG23	SEG24
3	X	X	X	X	X

On (SEG1 to SEG12)	Off (SEG13 to SEG24)
On 00 Auto	Off 00 Auto






Installation Procedure







Take the steps presented in the following table:

Steps	Remote control display
1 Set the SEG2 and SEG3 values: a Set the SEG2 value by pressing the  (Low Fan) button repeatedly until the value you want to set appears on the remote control display. b Set the SEG3 value by pressing the  (High Fan) button repeatedly until the value you want to set appears on the remote control display. When you press the  (Low Fan) or  (High Fan) button, values appear in the following order:  →  → ...  → 	 SEG2  SEG3
2 Press the  (Mode) button. Cool and On appear on the remote control display.	
3 Set the SEG4 and SEG5 values: a Set the SEG4 value by pressing the  (Low Fan) button repeatedly until the value you want to set appears on the remote control display. b Set the SEG5 value by pressing the  (High Fan) button repeatedly until the value you want to set appears on the remote control display. When you press the  (Low Fan) or  (High Fan) button, values appear in the following order:  →  → ...  → 	 SEG4  SEG5
4 Press the  (Mode) button. Dry and On appear on the remote control display.	
5 Set the SEG6 and SEG8 values: a Set the SEG6 value by pressing the  (Low Fan) button repeatedly until the value you want to set appears on the remote control display.	 SEG6

Steps	Remote control display
b Set the SEG8 value by pressing the  (High Fan) button repeatedly until the value you want to set appears on the remote control display. When you press the  (Low Fan) or  (High Fan) button, values appear in the following order:  →  → ...  → 	 SEG8
6 Press the  (Mode) button. Fan and On appear on the remote control display.	
7 Set the SEG9 and SEG10 values: a Set the SEG9 value by pressing the  (Low Fan) button repeatedly until the value you want to set appears on the remote control display. b Set the SEG10 value by pressing the  (High Fan) button repeatedly until the value you want to set appears on the remote control display. When you press the  (Low Fan) or  (High Fan) button, values appear in the following order:  →  → ...  → 	 SEG9  SEG10
8 Press the  (Mode) button. Heat and On appear on the remote control display.	
9 Set the SEG11 and SEG12 values: a Set the SEG11 value by pressing the  (Low Fan) button repeatedly until the value you want to set appears on the remote control display. b Set the SEG12 value by pressing the  (High Fan) button repeatedly until the value you want to set appears on the remote control display. When you press the  (Low Fan) or  (High Fan) button, values appear in the following order:  →  → ...  → 	 SEG11  SEG12


Installation Procedure

Steps	Remote control display
10 Press the  (Mode) button. Auto and Off appear on the remote control display.	
11 Set the SEG14 and SEG15 values: a Set the SEG14 value by pressing the  (Low Fan) button repeatedly until the value you want to set appears on the remote control display. b Set the SEG15 value by pressing the  (High Fan) button repeatedly until the value you want to set appears on the remote control display. When you press the  (Low Fan) or  (High Fan) button, values appear in the following order: 0 → 1 → ... E → F	 SEG14  SEG15
12 Press the  (Mode) button. Cool and Off appear on the remote control display.	
13 Set the SEG16 and SEG17 values: a Set the SEG16 value by pressing the  (Low Fan) button repeatedly until the value you want to set appears on the remote control display. b Set the SEG17 value by pressing the  (High Fan) button repeatedly until the value you want to set appears on the remote control display. When you press the  (Low Fan) or  (High Fan) button, values appear in the following order: 0 → 1 → ... E → F	 SEG16  SEG17
14 Press the  (Mode) button. Dry and Off appear on the remote control display.	
15 Set the SEG18 and SEG20 values: a Set the SEG18 value by pressing the  (Low Fan) button repeatedly until the value you want to set appears on the remote control display.	 SEG18

Steps	Remote control display
b Set the SEG20 value by pressing the  (High Fan) button repeatedly until the value you want to set appears on the remote control display. When you press the  (Low Fan) or  (High Fan) button, values appear in the following order:  →  → ...  → 	 SEG20
16 Press the  (Mode) button. Fan and Off appear on the remote control display.	
17 Set the SEG21 and SEG22 values: a Set the SEG21 value by pressing the  (Low Fan) button repeatedly until the value you want to set appears on the remote control display. b Set the SEG22 value by pressing the  (High Fan) button repeatedly until the value you want to set appears on the remote control display. When you press the  (Low Fan) or  (High Fan) button, values appear in the following order:  →  → ...  → 	 SEG21  SEG22
18 Press the  (Mode) button. Heat and Off appear on the remote control display.	
19 Set the SEG23 and SEG24 values: a Set the SEG23 value by pressing the  (Low Fan) button repeatedly until the value you want to set appears on the remote control display. b Set the SEG24 value by pressing the  (High Fan) button repeatedly until the value you want to set appears on the remote control display. When you press the  (Low Fan) or  (High Fan) button, values appear in the following order:  →  → ...  → 	 SEG23  SEG24

Installation Procedure


- 3 Check whether the option values that you have set are correct by pressing the  (Mode) button repeatedly



- 4 Save the option values into the indoor unit:
Point the remote control to the remote control sensor on the indoor unit and then press the  (Power) button on the remote control twice. Make sure that this command is received by the indoor unit. When it is successfully received, you can hear a short sound from the indoor unit. If the command is not received, press the  (Power) button again.
- 5 Check whether the air conditioner operates in accordance with the option values you have set:
- Reset the indoor unit by disconnecting and then reconnecting the power cable of the indoor unit or by pressing the RESET button on the outdoor unit.
 - Remove the batteries from the remote control, insert them again, and then press the  (Power) button on the remote control.

Setting the indoor unit addresses (MAIN/RMC/MCU)

- 1 Make sure that the power is supplied to the indoor unit.
 - If the indoor unit is not plugged in, it must include a power supply.
- 2 Make sure that the panel or display is connected to the indoor unit so that it can receive options.



- 3 Set an address (MAIN/RMC/MCU port) for each indoor unit using the remote control, according to your air conditioning system plan.

- The indoor unit addresses (MAIN/RMC/MCU port) are set to 0A0000-100000-200000-300000 by default.

NOTE

- MCU and Indoor unit addresses can also be modified using SNET Pro 2 service software (Add-on → Change address).
For more information, click on the "Help" button in SNET Pro 2.
- From SEG13 to SEG18 is for setting MCU address.
 - MCU models that can set address: MCU-S*NEK2N, MCU-S4NEK3N, MCU-S1NEK1N

Option No. for an indoor unit address:
0AXXXX-1XXXXX-2XXXXX-3XXXXX

Option	SEG1		SEG2		SEG3		SEG4		SEG5		SEG6	
Function	Page		Mode		Setting main address		100-digit of an indoor unit address		10-digit of an indoor unit address		The single digit of an indoor unit	
Indication and details	Indication	Details	Indication	Details	Indication	Details	Indication	Details	Indication	Details	Indication	Details
	0		A		0	No main address	0 to 9	10-digit	0 to 9	A single digit	0 to 3	A single digit
					1	Main address setting mode						
Option	SEG7		SEG8		SEG9		SEG10		SEG11		SEG12	
Function	Page		-		Setting RMC address		-		Group channel (x16)		Group address	
Indication and details	Indication	Details	-		Indication	Details	-		Indication	Details	Indication	Details
	1				0	No RMC address			RMC1	0 to F	RMC2	0 to F
					1	RMC address setting mode						

Installation Procedure

Option	SEG13		SEG14	SEG15		SEG16		SEG17		SEG18	
Function	Page		-	Setting MCU PORT address		10-digit of MCU address		1-digit of MCU		MCU PORT address	
Indication and details	Indication	Details	-	Indication	Details	Indication	Details	Indication	Details	Indication	Details
	2			0	No MCU PORT	0~1	10-digit	0~9	1-digit	A~F	PORT Location
				1	MCU PORT address setting mode						


⚠ CAUTION

- If you enter A to F to the SEG5 or SEG6, the indoor unit main address is not changed.
- If you enter 0 to the SEG 3, the indoor unit maintains the previous main address although you enter the option value for the SEG5 or SEG 6.
- If you enter 0 to the SEG 9, the indoor unit maintains previous RMC address although you enter the option value for the SEG11 or SEG12.
- You cannot set the SEG11 or SEG12 to F value at the same time.
- If the indoor unit is connected to the MCU, you can set the SEG 15~18.

Ex.) If you want to set the indoor unit to 'A' port of MCU #1.
(0A0000 – 100000 – 20101A -300000)

Setting the indoor unit installation option (suitable for the condition of each installation location)

- 1 Make sure that the power is supplied to the indoor unit.
 - If the indoor unit is not plugged in, it must include a power supply.
- 2 Make sure that the panel or display is connected to the indoor unit so that it can receive options




- 3 Set an address for each indoor unit using the remote control, according to your air conditioning system plan.
 - The indoor unit addresses are set to 020010-100000-200000-300000 by default.

Installation options for the 02 series

SEG1	SEG2	SEG3	SEG4	SEG5	SEG6
0	2	Evaporator Drying	Use of external room temperature sensor / Minimizing fan operation when thermostat is off	Use of central control	FAN RPM compensation
SEG7	SEG8	SEG9	SEG10	SEG11	SEG12
1	-	-	-	EEV Step when heating stops	Dew removal operation in WindFree mode
SEG13	SEG14	SEG15	SEG16	SEG17	SEG18
2	Use of external control	Setting the output of external control / External heater signal / Cooling operation signal / Free Cooling control signal	-	Buzzer control	Hours of filter usage
SEG19	SEG20	SEG21	SEG22	SEG23	SEG24
3	Individual control of a remote controller	Heating setting compensation / Removing condensate water in heating mode	Adjusted EEV step of stopped unit during oil return /defrost mode.	Motion detect sensor	-

- If you set the Maximum filter usage time (SEG18) option to a value other than 2 and 6, it is automatically set to 2 (1000 hours).
- If you set an option to a value that is out of range specified above, the option is automatically set to 0 by default.
- The SEG5 option (Use of central control) is set to 1 (Use) by default. Therefore, you don't need to set the SEG5 option additionally. Note that even if the central control system is not connected, no errors occur. If you want a specific indoor unit not to be controlled by the central control system, set the SEG option of that indoor unit to 0 (Disuse).
- The external output of SEG15 is generated via MIM-B14 connection. (Refer to the manual of MIM-B14.)
- If you set the Individual control with remote control (SEG20) option to a value other than 0 to 4, it is automatically set to 0 (Indoor1).



* The output of hot coil terminal is AC 220 V / 230 V
(The same as Indoor Unit's input Power)

Installation Procedure

02 series installation option (Detailed)

Option No. : 02XXXX-1XXXXX-2XXXXX-3XXXXX

Option	SEG1		SEG2		SEG3		SEG4			SEG5		SEG6	
Explanation	PAGE		MODE		Evaporator Drying		Use of external room temperature sensor / Minimizing fan operation when thermostat is off			Use of central control		FAN RPM compensation	
Indication and Details	Indication	Details	Indication	Details	Indication	Details	Indication	Details		Indication	Details	Indication	Details
								Use of External room temperature sensor	Minimizing fan operation when thermostat is off				
	0	2	0	Disuse	0	Default	Default	0	Disuse	0	Disuse		
					1	Use	Disuse						
			2	Use (5min) (*1)	2	Disuse	Use (Heating) (*2)			1	Use		
					3	Use	Use (Heating) (*2)						
			4	Use (10min) (*1)	4	Disuse	Use (Cooling) (*2)			1	Use		
					5	Use	Use (Cooling) (*2)						
			6	Use (30min) (*1)	6	Disuse	Use (Heating / Cooling) (*2)	2	High ceiling KIT (4way model only)				
					7	Use	Use (Heating / Cooling) (*2)						
					8	Disuse	Use (Cooling Ultra Low Fan) (*2)						
					9	Use	Use (Cooling Ultra Low Fan) (*2)						
					A	Disuse	Use (Heating / Cooling Ultra Low Fan) (*2)						
					B	Use	Use (Heating / Cooling Ultra Low Fan) (*2)						

Option	SEG7		SEG8		SEG9		SEG10			SEG11		SEG12								
Explanation	PAGE		-		-		-			EEV Step when heating stops		Dew removal operation in WindFree mode								
Indication and Details	Indication	Details	-		-		-			Indication	Details	Indication	Details							
	1									0	Default	0	(Default) Maintain blade status in WindFree mode							
										1	Adjusted EEV Step setting	1	Cooling operation by opening the blade							

Option	SEG13		SEG14		SEG15		SEG16		SEG17		SEG18			
Explanation	PAGE		Use of external control		Setting the output of external control / External heater signal / Cooling operation signal / Free Cooling control signal		-		Buzzer control		Hours of filter usage			
Indication and Details	Indication	Details	Indication	Details		Indication	Details		-	Indication	Details	Indication	Details	
	2		0	Disuse	Normal Signal Control (*4)	0	External control (Thermo On)	0		Use buzzer	2	1000 Hour		
			1	ON/OFF control		1	External control (Operation On)							
			2	OFF control		2	External heater signal (*5)							
			3	Window ON/OFF control		3	External heater signal (*5)							
			8	Disuse	Reverse Signal Control (*4)	4	Cooling operation signal (*6)	1		Disuse buzzer	6	2000 Hour		
			9	ON/OFF control		5	Free Cooling control (Cooling Thermo On) (*7)							
			A	OFF control		6	Free Cooling control (Cooling/ Dry Thermo On) (*7)							
			B	Window ON/OFF control										
Option	SEG19		SEG20		SEG21		SEG22		SEG23		SEG24			
Explanation	PAGE		Individual control of a remote controller		Heating setting compensation / Removing condensate water in heating mode		Adjusted EEV step of stopped unit during oil return /defrost mode.		Motion detect sensor		-			
Indication and Details	Indication	Details	Indication	Details		Indication	Details		Indication	Details		-		
	3		0 or1	channel 1	0	Default	Disuse	0	Default	0	Disuse			
					1	3.6°F(2°C)	Disuse			1	Turn out in 30min. without motion			
			2	channel 2	2	9°F(5°C)	Disuse			0	Default		2	Turn out in 60min. without motion
					3	Default	Use (*8)						3	Turn out in 120min. without motion
			3	channel 3	4	3.6°F(2°C)	Use (*8)						1	Adjusted EEV positon
								5	9°F(5°C)	Use (*8)	5			
			4	channel 4	5	9°F(5°C)	Use (*8)	1	Adjusted EEV positon	6	Turn out in 60min. without motion & *advanced function			
										7	Turn out in 120min. without motion & *advanced function			
										8	Turn out in 180min. without motion & *advanced function			

Installation Procedure

* Advanced function: Controlling cooling/heating current or power saving with motion detect.

(*1) When Cooling or Dry mode turns off, the indoor fan will operate for the specified amount of time.

(*2) Minimizing fan operation when thermostat is off

- Fan operates for 20 seconds at an interval of 5 minutes in heat mode.
- Fan stops or operates Ultra low in Cooling when thermostat is off.

(*3) 1: Fan is turned on continually when the hot water heater is turned on,

3: Fan is turned off when the hot water heater is turned on with cooling only indoor unit

Cooling only indoor unit: To use this option, install the Mode Select switch(MCM-C200) on the outdoor unit and fix it as cool mode.

If the "Cooling Priority" option is set in the Heat Pump outdoor unit, the indoor unit can operate in the Heat mode owing to the water heater even if the outdoor unit is running in the Cool mode.

(*4) When Normal Signal Control is enabled, the external control is turned on by the short-circuit signal and off by the open-circuit signal.

When Reverse Signal Control is enabled, the external control is turned off by the short-circuit signal and on by the open-circuit signal.

(*5) When the following 2 or 3 is used as external heater On/Off signal, the signal for monitoring external contact control will not be output.

2: Fan is turned on continually when the external heater is turned on,

3: Fan is turned off when the external heater is turned on with cooling only indoor unit

Cooling only indoor unit: To use this option, install the Mode Select switch(MCM-C200) on the outdoor unit and fix it as cool mode.

- If Fan is set to off for cooling only indoor unit by setting the SEG15=3, you need to use an external sensor or wired remote controller sensor to detect indoor temperature exactly.

- If the "Cooling Priority" option is set in the Heat Pump outdoor unit, the indoor unit can operate in Heat mode operating a field-provided external heater even if the outdoor unit is running in Cool mode.

(*6) When indoor unit is in cooling or Dry mode, The output signal is "ON"

(*7) For free cooling control, a field provided economizer controller is required.

(*8) If the air conditioner operates in heating mode immediately after operating in cooling mode, the condensate water in the drain pan may become water vapor from the heat at the indoor unit heat exchanger. Water vapor may condense on the indoor unit which may fall into the occupied space, use this function to get rid of the water vapor from of from the indoor unit by operating the fan (for maximum 20 minutes) even when the indoor unit is turned off after cooling mode is turned to heating mode.

05 series installation option

SEG1	SEG2	SEG3	SEG4	SEG5	SEG6
0	5	Use of Auto Change Over for HR only in Auto mode / Use of Cooling only indoor unit of HR	(When setting SEG3) Standard heating temp. Offset	(When setting SEG3) Standard cooling temp. Offset	(When setting SEG3) Standard for mode change Heating → Cooling
SEG7	SEG8	SEG9	SEG10	SEG11	SEG12
1	(When setting SEG3) Standard for mode change Cooling → Heating	(When setting SEG3) Time required for mode change (*1)	Compensation option for Long pipe or height difference between indoor units	MTFC (*4)	-
SEG13	SEG14	SEG15	SEG16	SEG17	SEG18
2	-	-	-	-	Control variables when using hot water / external heater (*5)
SEG19	SEG20	SEG21	SEG22	SEG23	SEG24
3	-	-	-	Forced FAN Operation for Heating and Cooling	-

Installation Procedure

05 series installation option (Detailed)

Option No. : 05XXXX-1XXXX-2XXXX-3XXXX

Option	SEG1		SEG2		SEG3		SEG4		SEG5		SEG6						
Explanation	PAGE		MODE		Use of Auto Change Over for HR only in Auto mode / Use of Cooling only indoor unit of HR		(When setting SEG3) Standard heating temp. Offset		(When setting SEG3) Standard cooling temp. Offset		(When setting SEG3) Standard for mode change Heating → Cooling						
Indication and Details	Indication	Details	Indication	Details	Indication	Details	Indication	Details	Indication	Details	Indication	Details					
	0		5		0	Follow product option	0	0°F(0°C)	0	0°F(0°C)	0	1.8°F(1°C)					
							1	0.9°F(0.5°C)	1	0.9°F(0.5°C)	1	2.7°F(1.5°C)					
					1	Use Auto Change Over for HR only	2	1.8°F(1°C)	2	1.8°F(1°C)	2	3.6°F(2°C)					
							3	2.7°F(1.5°C)	3	2.7°F(1.5°C)	3	4.5°F(2.5°C)					
							4	3.6°F(2°C)	4	3.6°F(2°C)	4	5.4°F(3°C)					
							2	Use Cooling only indoor unit for HR	5	4.5°F(2.5°C)	5	4.5°F(2.5°C)	5	6.3°F(3.5°C)			
					6	5.4°F(3°C)			6	5.4°F(3°C)	6	7.2°F(4°C)					
					7	6.3°F(3.5°C)			7	6.3°F(3.5°C)	7	8.1°F(4.5°C)					
Option					SEG7		SEG8		SEG9		SEG10		SEG11		SEG12		
Explanation	PAGE		(When setting SEG3) Standard for mode change Cooling → Heating		(When setting SEG3) Time required for mode change (*1)		Compensation option for Long pipe or height difference between indoor units		MTFC (*4)		-						
Indication and Details	Indication	Details	Indication	Details	Indication	Details	Indication	Details	Indication	Details	-						
	1		0	1.8°F(1°C)	0	5min	0	Default	0	Default							
			1	2.7°F(1.5°C)	1	7min	1	(*2) Height difference is more than 30m or (*3) Distance is longer than 110m									
			2	3.6°F(2°C)	2	9min											
			3	4.5°F(2.5°C)	3	11min											
			4	5.4°F(3°C)	4	13min	2	(*2) Height difference is 15~30m or (*3) Distance is 50~110m	2	Use							
			5	6.3°F(3.5°C)	5	15min											
			6	7.2°F(4°C)	6	20min											
			7	8.1°F(4.5°C)	7	30min											


Option	SEG13		SEG14	SEG15	SEG16	SEG17	SEG18		
Explanation	PAGE		-	-	-	-	Control variables when using hot water / external heater (*5)		
Indication and Details	Indication	Details	-	-	-	-	Indication	Details	
	2	Set temp. for heater On/Off					Delay time for heater On		
		0					At the same time as thermo on		No delay
		1					At the same time as thermo on		10 minutes
		2					At the same time as thermo on		20 minutes
		3					2.7°F(1.5°C)		No delay
		4					2.7°F(1.5°C)		10 minutes
		5					2.7°F(1.5°C)		20 minutes
		6					5.4°F(3.0°C)		No delay
		7					5.4°F(3.0°C)		10 minutes
		8					5.4°F(3.0°C)		20 minutes
		9					8.1°F(4.5°C)		No delay
		A					8.1°F(4.5°C)		10 minutes
		B					8.1°F(4.5°C)		20 minutes
		C					10.8°F(6.0°C)		No delay
D	10.8°F(6.0°C)		10 minutes						
E	10.8°F(6.0°C)		20 minutes						
Option	SEG19		SEG20	SEG21	SEG22	SEG23		SEG24	
Explanation	PAGE		-	-	-	Forcing FAN Operation for Heating and Cooling		-	
Indication and Details	Indication	Details	-	-	-	Indication	Details		-
	3	Cooling Fan Setting				Heating Fan Setting			
		0				Disuse	Disuse		
		1				Disuse	Use (Fan: User setting)		
		2				Disuse	Use (Fan: High)		
		3				Disuse	Use (Fan: Low)		
		4				Use (Fan: User setting)	Disuse		
		5				Use (Fan: User setting)	Use (Fan: User setting)		
		6				Use (Fan: User setting)	Use (Fan: High)		
		7				Use (Fan: User setting)	Use (Fan: Low)		
		8				Use (Fan: High)	Disuse		
		9				Use (Fan: High)	Use (Fan: User setting)		
		A				Use (Fan: High)	Use (Fan: High)		
		B				Use (Fan: High)	Use (Fan: Low)		
		C				Use (Fan: Low)	Disuse		
		D				Use (Fan: Low)	Use (Fan: User setting)		
		E				Use (Fan: Low)	Use (Fan: High)		
		F				Use (Fan: Low)	Use (Fan: Low)		

Installation Procedure

- (*1) Duration for Auto Change Over triggered when you set dual set points in the Auto mode using the wired remote control MWR-WG00*N.
- During the automatic heating operation, if the specified time has elapsed in the state of "the room temperature > the cooling temperature in the Auto mode + the primary cooling temperature (set in the Auto Change Over screen after entering the User mode by pressing the  button on the wired remote control)" the air conditioner changes into the automatic cooling operation.
- During the automatic cooling operation, if the specified time has elapsed in the state of "the room temperature < the heating temperature in the Auto mode - the primary heating temperature (set in the Auto Change Over screen after entering the User mode by pressing the  button on the wired remote control)" the air conditioner changes into the automatic heating mode.
- (*2) Height difference : The difference of the height between the corresponding indoor unit and the indoor unit installed at the lowest place. For example, When the indoor unit is installed 131.23ft(40m) higher than the indoor unit installed at the lowest place, select the option "1".
- (*3) The difference between the pipe length of the indoor unit installed at farthest place from an outdoor unit and the pipe length of the corresponding indoor unit from an outdoor unit.
- For example, when the farthest pipe length is 328 ft (100 m) and the corresponding indoor unit is 131.23ft(40m) away from an outdoor unit, select the option "2". (328ft(100m) - 131.23ft(40m) = 196.85ft(60m))
- (*4) For MTFC option, the MTFC (Multi Tenant Function Controller) accessory kit is required (purchased separately).
- (*5) Heater operation when the SEG9 of 02 series installation option is set to using hot water heater or when SEG15 is set to using external heater.
- Example 1) Setting 02 series SEG9 ="1" / Setting 05 series SEG18 ="0": The hot water heater is turned on at the same time as the heating thermostat is on, and turned off when the heating thermostat is off.
- Example 2) Setting 02 series SEG15 ="2" / Setting 05 series SEG18 ="A": Room temp. ≤ set temp. + f (heating compensation temp.)
- External heater is turned on when the temperature is maintained as 8.1°F(4.5°C) for 10 minutes. Room temp. > set temp. + f(heating compensation temp.)
 - External heater is turned off when the temperature is maintained as 8.1°F(4.5°C) + 1.8°F(1°C) (1.8°F(1°C) is the Hysteresis for On/Off selection.)

Additional information on SEG 3, 4, 5, 6, 8, 9

When SEG 3 is set to 1 and the HR-specific auto changeover function is run, the indoor unit operates as shown in the following figure:



The mode change between the Cool and Heat modes is made only when the thermo off state is maintained for the period of time set with SEG9.

Installation Procedure


Changing the addresses and options individually

When you want to change the value of a specific option, refer to the following table and follow the steps in **Common steps for setting address and options** on page 25.

Option	SEG1		SEG2		SEG3		SEG4		SEG5		SEG6	
Function	Page		Mode		Type of the option to change		Tens position of the option number		Units position of the option number		New value	
Indication and details	Indication	Details	Indication	Details	Indication	Details	Indication	Details	Indication	Details	Indication	Details
	0		D		Option type	0 to F	Tens position value	0 to 9	Units position value	0 to 9	New value	0 to F

Example: Changing the Buzzer control (SEG17) option of the installation options to 1 disuse.

Option	SEG1		SEG2		SEG3		SEG4		SEG5		SEG6	
Function	Page		Mode		Type of the option to change		Tens position of the option number		Units position of the option number		New value	
Indication	0		D		2		1		7		1	



CAUTION

- Mixed operation (two or more indoor units operate in different modes simultaneously) is not available when the indoor units are connected to the same heat pump outdoor unit (not heat recovery). If you set an indoor unit as the main indoor unit by using the remote control, the outdoor unit will automatically operate in the current mode of the main indoor unit.

Performing final check and trial operation

To complete the installation, perform the following checks and tests to ensure that the air conditioner operates correctly.

- Check the followings.
 - Strength of the installation site
 - Tightness of pipe connection to detect a gas leak
 - Electric wiring connections
 - Heat-resistant insulation of the pipe
 - Drainage
 - Earth conductor connection
 - Correct operation (follow the steps below)

After finishing the installation of the air conditioner, you should explain the following to the user. Refer to appropriate pages in the User's Manual.

- 1 How to start and stop the air conditioner
- 2 How to select the modes and functions
- 3 How to adjust the temperature and fan speed
- 4 How to adjust the airflow direction
- 5 How to set the timers
- 6 How to clean and replace the filters

 NOTE

- When you complete the installation successfully, hand over the User's Manual and this Installation Manual to the user for storage in a handy and safe place.


Emergency Temperature Output (ETO) function

 CAUTION

- In order to deploy the ETO function, the MIM-B14, an external contact interface module, must be installed in each indoor unit.
 - The ETO is a concept of emergency operation of indoor units. If the indoor unit 1 (main indoor unit) stops because of an error, the indoor unit 2 (sub indoor unit) starts to operate.
 - Basically, the indoor unit 2 operates in the previous mode. [For the first time operation, it starts in 75.2°F(24°C) Auto mode.]
 - To set more detailed operation conditions for the indoor unit, use S-NET Pro 2 service software


Installation Procedure

Setting up the ETO



Main indoor unit


- 1 Disable the external contact control (Default).
- 2 Connect S-net pro2 to F1 and F2.
- 3 Enable the ETO function and set the temperature and time in S-net pro2.
 - Setting the main indoor unit in S-net pro2



- a Select an emergency temperature output(ETO) mode.
- b Select the main indoor unit.
- c Set the duration used as a reference for generating emergency output.
- d Set the reference temperature at which emergency output is generated.
 - In the Cool mode, emergency output is generated when the room temperature becomes higher than the lower of the set temperature and ETO setting temperature.
 - In the Heat mode, emergency output is generated when the room temperature becomes lower than the higher of the set temperature and ETO setting temperature.

Sub indoor unit (backup Unit)

- 1 (Required) Enable the external contact control (with the installation option 02 series SEG14 - Reverse Control).
- 2 Connect the S-net pro2 to F1 and F2.
- 3 Enable the entrance control and set the mode, set temperature, and fan speed in the S-net pro2.
 - Setting the sub indoor unit in the S-net pro2



- a Select Control for Entering Room.
- b Select the sub indoor unit.
- c Set the operation mode, fan speed, and set temperature.

- Operation when the external contact settings and the ETO settings overlap

Main indoor unit	Enable of ETO	Enable of external contact	Error port output
	X	X	N/A
	X	O	Output due to an error
	O	X	Output by ETO entrance conditions (temperature / time / error occurrence)
Sub indoor unit	O	O	Output by ETO entrance conditions (temperature / time / error occurrence) ※ Ready to control the main contact input

Sub indoor unit	Enable of entrance control	Enable of external contact	Operation when outputting Main
	X	X	N/A
	X	O	On with the previous operation conditions
	O	O	On with the entrance control enabled

Appendix

Troubleshooting

Detection of errors

- If an error occurs during the operation, an LED flickers and the operation is stopped except the LED.
- If you re-operate the air conditioner, it operates normally at first, then detect an error again.

LED Display on the receiver & display unit

Abnormal condition	Error code	Indoor unit display indications				
						
		Ice Blue	Yellow Green			
Error on indoor temperature sensor (Short or Open)	E121	X	X		X	X
1. Error on Eva-in sensor (Short or Open)	E122		X		X	X
2. Error on Eva-out sensor (Short or Open)	E123					
3. Discharge sensor error (Short or Open)	E126					
Indoor fan error	E154	X	X	X		X
1. Error on outdoor temperature sensor (Short or Open)	E221		X	X		X
2. Error on cond sensor	E237					
3. Error on discharge sensor	E251					
Other outdoor unit sensor error that is not on the above list						
1. When there is no communication between the indoor-outdoor units for 2 minutes	E101	X	X			X
2. Communication error received from the outdoor unit	E102					
3. 3 minute tracking error on outdoor unit	E202					
4. Communication error after tracking due to unmatching number of installed units	E201					
5. Error due to repeated communication address	E108					
6. Communication address not confirmed	E109					
Other outdoor unit communication error that is not on the above list						
Self diagnosis error display		X	X			
1. Error due to opened EEV (2nd detection)	E151					
2. Error due to closed EEV (2nd detection)	E152					
3. Eva in sensor is detached	E128					
4. Eva out sensor is detached	E129					
5. Thermal fuse error (Open)	E198					

Abnormal condition	Error code	Indoor unit display indications				
						
		Ice Blue	Yellow Green			
1. COND mid sensor is detached	E241	X	X			
2. Refrigerant leakage (2nd detection)	E554					
3. Abnormally high temperature on Cond (2nd detection)	E450					
4. Low pressure s/w (2nd detection)	E451					
5. Abnormally high temperature on discharged air on outdoor unit (2nd detection)	E416					
6. Indoor operation stop due to unconfirmed error on outdoor unit	E559					
7. Error due to reverse phase detection	E425					
8. Comp stop due to freeze detection (6th detection)	E403					
9. High pressure sensor is detached	E301					
10. Low pressure sensor is detached	E306					
11. Outdoor unit copression ration error	E428					
12. Outdoor sump down_1 prevetion control	E413					
13. Compressor down due to low pressure sensor prevention control_1	E410					
14. Simultaneous opening of cooling/heating MCU SOL valve (1st detection)	E180					
15. Simultaneous opening of cooling/heating MCU SOL valve (2nd detection)	E181					
Other outdoor unit self-diagnosis error that is not on the above list						
Flowating s/w (2nd detection)	E153	X	X	X		
EEPROM error	E162					
EEPROM option error	E163					
Error due to incompatible indoor unit	E164	X	X	X	X	

● : On, ◐ : Blinking, X : Off

- If you turn off the air conditioner when the LED is flickering, the LED is also turned off.
- If you re-operate the air conditioner, it operates normally at first, then detect an error again.
- When E108 error occurs, change the address and reset the system.
Ex.) When address of the indoor unit #1 and #2 are set as 5, address of the indoor unit #1 will become 5 and indoor unit #2 will display E108, A002.

