



Angled Hose Connector

**Maximize your time outdoors
with easier water access.**



Angled for Ease of Use

Angled handle for extra leverage. Perfect for anyone with arthritis or joint pain.



Leak-Proof Connections

Attaches to any hose, providing instant water connections – even under full pressure.



Wear-Resistant Materials

Manufactured from crush-proof, military-grade acetal polymer.

**Learn More
About Aquor**



Aquor® Angled Hose Connector


04/2025
CN-AN-SERIES
Tech Specs



CN-AN-B



CN-AN-BLK



Connect instantly under full water pressure with a simple push and twist. Leave attached to any hose for quick and easy Hydrant connections. Downturned handle provides extra leverage. Perfect for higher water pressures or anyone with arthritis.

- Universally compatible with 3/4" GHT
- Built-in check valve prevents backflow
- Angled for easier connection
- Durable military-grade materials

Compatibility	All Aquor Hydrants and outlets
Outlet	3/4" GHT (m)
Backflow Protection	Yes, check valve in Hose Connector
Operating Temperature	33-140°F
Operating Water Pressure	25-125 PSI
Flow Rate	6.8 GPM @ 52 PSI
Connector Material	Acetal polymer
O-Ring Material	Fluorocarbon rubber
Colors Available	Aquor Blue and Jet Black
Warranty	5-year limited warranty

Care and Usage Tips


- Positionable in multiple directions
- Leave attached to your hose for easy use
- Unplug from Hydrant after each use to allow for proper drainage
- Store out of the elements to extend connector life

Aquor® Angled Hose Connector

04/2025
CN-AN-SERIES
How to Use

As Easy as 1, 2, 3

- 1** Securely attach Aquor Hose Connector to any hose. Leave connected for convenience.



- 2** Align the 3 grooves on the Hose Connector with the nibs on the Hydrant. Gently push in, then turn clockwise to connect. This opens the valve, and water flow starts instantly. Positionable in multiple directions.




- 3** Disconnect by pushing in and turning counterclockwise. Your Hydrant will drain automatically. We recommend depressurizing your hose and storing out of the elements.




Removing the Check Valve

- 1** Unthread the plastic packing nut.



- 2** Remove the spring and check valve.



Aquor® Angled Hose Connector

04/2025
CN-AN-SERIES
Hose Connector Comparison

Model	Backflow Protection	Hydrant Compatibility	Flow Control	Colors Available	Certifications
	Check Valve	All Aquor Hydrants and Outlets	None	Slate Gray, Jet Black, Aquor Blue	None
Current Product 	Check Valve	All Aquor Hydrants and Outlets	None	Aquor Blue, Jet Black	None
	None	All Aquor Hydrants and Outlets	Yes	Slate Gray, Jet Black	None
	Vacuum Breaker	All Aquor Hydrants and Outlets	None	Slate Gray, Jet Black	ASSE 1019, CSA B125
	Vacuum Breaker	All Aquor Hydrants and Outlets	Yes	Slate Gray, Jet Black	ASSE 1019, CSA B125
	Vacuum Breaker	All Aquor Hydrants and Outlets	Yes	Slate Gray, Jet Black (Coming Soon)	ASSE 1019, CSA B125