

STAINLESS STEEL



4" DECK MOUNT FAUCET WITH SWING SPOUT			
HANDLE TYPE		CATEGORY	DESCRIPTION
LEVER	WRIST		
53740	58564	Stainless Steel	4" Deck Faucet 6" Swing Spout
53759	58572	Stainless Steel	4" Deck Faucet 8" Swing Spout
53767	58580	Stainless Steel	4" Deck Faucet 10" Swing Spout
53775	58599	Stainless Steel	4" Deck Faucet 12" Swing Spout
53783	58602	Stainless Steel	4" Deck Faucet 14" Swing Spout
53791	58610	Stainless Steel	4" Deck Faucet 16" Swing Spout



4" DECK MOUNT FAUCET WITH DOUBLE JOINTED SWING SPOUT			
HANDLE TYPE		CATEGORY	DESCRIPTION
LEVER	WRIST		
53805	58629	Stainless Steel	4" Deck Faucet 6" Swing Spout, 7"DJ
53813	58637	Stainless Steel	4" Deck Faucet 8" Swing Spout, 7"DJ
53821	58645	Stainless Steel	4" Deck Faucet 10" Swing Spout, 7"DJ
53848	58653	Stainless Steel	4" Deck Faucet 12" Swing Spout, 7"DJ
53856	58661	Stainless Steel	4" Deck Faucet 14" Swing Spout, 7"DJ
53864	58688	Stainless Steel	4" Deck Faucet 16" Swing Spout, 7"DJ



4" DECK MOUNT FAUCET WITH SWIVEL/RIGID GOOSENECK			
HANDLE TYPE		CATEGORY	DESCRIPTION
LEVER	WRIST		
53872	58696	Stainless Steel	4" Deck Faucet 6" Swivel/Rigid Gooseneck Spout
53880	58718	Stainless Steel	4" Deck Faucet 12" Swivel/Rigid Gooseneck Spout



lever handles



wrist handles