

STAINLESS STEEL



8" BACKSPLASH MOUNT FAUCET WITH SWING SPOUT			
HANDLE TYPE		CATEGORY	DESCRIPTION
LEVER	WRIST		
61220	61239	SS	8" BS Mount Faucet 6" Swing Spout
61093	61107	SS	8" BS Mount Faucet 8" Swing Spout
60968	60976	SS	8" BS Mount Faucet 10" Swing Spout
60836	60844	SS	8" BS Mount Faucet 12" Swing Spout
60690	60704	SS	8" BS Mount Faucet 14" Swing Spout
60569	60577	SS	8" BS Mount Faucet 16" Swing Spout



8" BACKSPLASH MOUNT FAUCET WITH DOUBLE JOINTED SWING SPOUT			
HANDLE TYPE		CATEGORY	DESCRIPTION
LEVER	WRIST		
61166	61174	SS	8" BS Mount Faucet 6" Swing Spout, 7"DJ
61034	61042	SS	8" BS Mount Faucet 8" Swing Spout, 7"DJ
60895	60909	SS	8" BS Mount Faucet 10" Swing Spout, 7"DJ
60755	60763	SS	8" BS Mount Faucet 12" Swing Spout, 7"DJ
60623	60631	SS	8" BS Mount Faucet 14" Swing Spout, 7"DJ
60496	60518	SS	8" BS Mount Faucet 16" Swing Spout, 7"DJ



8" BACKSPLASH MOUNT FAUCET WITH SWIVEL/RIGID GOOSENECK			
HANDLE TYPE		CATEGORY	DESCRIPTION
LEVER	WRIST		
61476	61484	SS	8" BS Mount Faucet 6" Swivel/Rigid Gooseneck Spout
61298	61301	SS	8" BS Mount Faucet 12" Swivel/Rigid Gooseneck Spout



FISHER