


## Nos. 711 & 911 Self-Opening Die Heads




**NOTE: Order parts by Catalog Number only.  
DO NOT order by Reference Number.**

| Ref. No. | Catalog No. | Description                              |
|----------|-------------|------------------------------------------|
| —        | 26132       | 711 Self-Opening Die Head (NPT)          |
| —        | 26137       | 911 Self-Opening Die Head (BSPT)         |
| —        | 41382       | 911 Self-Opening Die Head f/Japan (BSPT) |
| —        | 46862       | 911 Self-Opening Die Head f/Europe       |
| 1        | 44240       | Bushing                                  |
| 2        | 43830       | Throw-out Lever                          |
| 3        | 44265       | Throw-out Link                           |
| 4        | 44245       | Thrust Washer                            |
| 5        | 44260       | Clamp Lever                              |
| 6        | 44270       | Spiral Pin                               |
| 7        | 45055       | Insert                                   |
| 8        | 44250       | Nut                                      |
| 9        | 44255       | Retaining Ring                           |
| 10       | 44275       | Throw-out Plunger                        |
| 11       | 11565       | Spring                                   |
| 12       | 44290       | Trigger Screw                            |
| 13       | 44235       | Lock Screw                               |
| 14       | 32205       | Screw 1/4" - 20 x 5/8                    |
| 15       | 45050       | Pin                                      |
| 16       | 97020       | Retaining Ring                           |
| 17       | 40942       | Cam Plate (NPT)                          |
|          | 97040       | Cam Plate (BSPT)                         |
| 18       | 26717       | Head w/Post                              |
| 19       | 44285       | Trigger Assy.                            |
|          | 32982       | Adjustable Trigger Assy. (Europe)        |
|          | 44687       | Stepped Trigger Assy. (Japan)            |
| †20      | 59827       | Post                                     |
| 21       | 39982       | Spring                                   |
| 22       | 44460       | O-Ring                                   |
| 23       | 39967       | Screw (Left Hand)                        |
| 24       | 39977       | Trigger Pivot                            |
| 25       | 39972       | Adjustable Trigger (Europe)              |
|          | 44672       | Stepped Trigger (Japan)                  |
|          | 45327       | Stepped Trigger (Europe)                 |
| 26       | 45332       | Adj. Gage Plate Assy.                    |
| 27       | 46722       | Adj. Lock Screw                          |
| 28       | 46717       | Adj. Gage Plate                          |
| 29       | 47147       | Button Head Screw                        |

† - See Service Notes

## Nos. 541, 542, 713 & 913 Quick-Opening Die Heads



| Ref. No. | Catalog No. | Description                                 |
|----------|-------------|---------------------------------------------|
| —        | 26162       | 541 Quick-Opening Bolt Die Head 1/4" - 1"   |
| —        | 26167       | 542 Quick-Opening Bolt Die Head 1 1/8" - 2" |
| —        | 26142       | 713 Quick-Opening Die Head (NPT) 1/4" - 2"  |
| —        | 26147       | 913 Quick-Opening Die Head (BSPT) 1/4" - 2" |
| 1        | 32205       | Screw 1/4" - 20 x 5/8 (4)                   |
| 2        | 23292       | Retaining Ring L.H. (713, 913)              |
|          | 46620       | Retaining Ring (541)                        |
|          | 46625       | Retaining Ring (542)                        |
| 3        | 43360       | Cam Plate L.H. (713, 913)                   |
|          | 43405       | Cam Plate (541)                             |
|          | 43410       | Cam Plate (542)                             |
| 4        | 46520       | Throw-out Lever (713, 913)                  |
|          | 46555       | Throw-out Lever (541, 542)                  |
| 5        | 39860       | Lock Screw (713, 913)                       |
|          | 39955       | Lock Screw (541, 542)                       |
| 6        | 39950       | Link                                        |
| 7        | 26897       | Head w/Post & Latch Assembly (913)          |
|          | 26982       | Head w/Post (541)                           |
|          | 26987       | Head w/Post (542)                           |
|          | 27267       | Head w/Post & Latch Assembly (713)          |
| 8        | 39460       | Lever Washer                                |
| 9        | 39970       | Clamp Lever                                 |
| †10      | 59827       | Post                                        |

† - See Service Notes