


MPAHU Exploded Views and Parts List

■ AM012/018/024/030/036/048/054/060/072TNZDCH/AA



■ Parts List : AM012/018/024/030/036/048/054/060/072TNZDCH/AA

No	Parts Code									Description	Q'TY
	AM012TNZDCH	AM018TNZDCH	AM024TNZDCH	AM030TNZDCH	AM036TNZDCH	AM048TNZDCH	AM054JNZDCH	AM060TNZDCH	AM072TNZDCH		
1	DB81-04202A	DB81-04202B	DB81-04202H	DB81-04202C	DB81-04202D	DB81-04202E	DB81-04202F	DB81-04202G	DB81-04202J	A/S-HEAT EXCHANGER	1
2	DB81-04200A	DB81-04200A	DB81-04200A	DB81-04200B	DB81-04200B	DB81-04200C	DB81-04200C	DB81-04200C	DB81-04200D	A/S-BLOWER CASE	1
3	DB81-04197A	DB81-04197A	DB81-04197A	DB81-04197B	DB81-04197B	DB81-04197C	DB81-04197C	DB81-04197C	DB81-04197C	A/S-BRACKET CABI	1
4	DB81-04198A	DB81-04198A	DB81-04198A	DB81-04198A	DB81-04198A	DB81-04198A	DB81-04198A	DB81-04198A	DB81-04198A	A/S-BRACKET MOTOR LEG	1
5	DB81-04199A	DB81-04199A	DB81-04199A	DB81-04199A	DB81-04199A	DB81-04199A	DB81-04199A	DB81-04199A	DB81-04199A	A/S-BRAKCET MOTOR MIDDLE	1
6	DB81-04194A	DB81-04194A	DB81-04194A	DB81-04194B	DB81-04194B	DB81-04194C	DB81-04194C	DB81-04194C	DB81-04194C	A/S-CABI BACK	1
7	DB81-04196A	DB81-04196A	DB81-04196A	DB81-04196B	DB81-04196B	DB81-04196C	DB81-04196C	DB81-04196C	DB81-04196C	A/S-CABI FRONT DOWN	1
8	DB81-04179A	DB81-04179A	DB81-04179A	DB81-04179A	DB81-04179A	DB81-04179A	DB81-04179A	DB81-04179A	DB81-04179A	A/S-CABI FRONT DOWN SVC	1
9	DB81-04180A	DB81-04180A	DB81-04180A	DB81-04180B	DB81-04180B	DB81-04180C	DB81-04180C	DB81-04180C	DB81-04180C	A/S-CABI FRONT UP	1
10	DB81-04181A	DB81-04181A	DB81-04181A	DB81-04181B	DB81-04181B	DB81-04181C	DB81-04181C	DB81-04181C	DB81-04181C	A/S-CABI TOP	1
11	DB81-04182A	DB81-04182A	DB81-04182A	DB81-04182A	DB81-04182A	DB81-04182A	DB81-04182A	DB81-04182A	DB81-04182A	A/S-TRANSFORMER	1
12	DB81-04183A	DB81-04183A	DB81-04183A	DB81-04183B	DB81-04183B	DB81-04183C	DB81-04183C	DB81-04183C	DB81-04183C	A/S-DRAIN PAN	1
13	DB81-04184A	DB81-04184A	DB81-04184A	DB81-04184B	DB81-04184B	DB81-04184C	DB81-04184C	DB81-04184C	DB81-04184C	A/S-DRAIN PAN SIDE	1
14	DB81-05891A	DB81-05892A	DB81-05893A	DB81-05894A	DB81-05895A	DB81-05896A	DB81-05897A	DB81-05898A	DB81-05899A	A/S-FAN MOTOR	1
15	DB81-04186A	DB81-04186A	DB81-04186A	DB81-04186A	DB81-04186A	DB81-04186A	DB81-04186A	DB81-04186A	DB81-04186A	A/S-RELAY A	3
16	DB81-04203A	DB81-04203A	DB81-04203A	DB81-04203A	DB81-04203A	DB81-04203A	DB81-04203A	DB81-04203A	DB81-04203A	A/S-FUSE	1
17	DB81-04204A	DB81-04204A	DB81-04204A	DB81-04204A	DB81-04204A	DB81-04204A	DB81-04204A	DB81-04204A	DB81-04204A	A/S-FUSE HOLDER AND FUSE	1
18	DB32-00236A	DB32-00236A	DB32-00236A	DB32-00236A	DB32-00236A	DB32-00236A	DB32-00236A	DB32-00236A	DB32-00236A	SENSOR TEMP	1
19	DB65-00179F	DB65-00179F	DB65-00179F	DB65-00179F	DB65-00179F	DB65-00179F	DB65-00179F	DB65-00179F	DB65-00179F	TERMINAL BLOCK	1
20	DB81-00635A	DB81-00635A	DB81-00635A	DB81-00635A	DB81-00635A	DB81-00635A	DB81-00635A	DB81-00635A	DB81-00635A	SPRING ETC-SENSOR	1
21	DB92-02786A	DB92-02786A	DB92-02786A	DB92-02786A	DB92-02786A	DB92-02786A	DB92-02786A	DB92-02786A	DB92-02786A	ASSY PCB MAIN	1
22	DB93-09220A	DB93-09220A	DB93-09220A	DB93-09220A	DB93-09220A	DB93-09220A	DB93-09220A	DB93-09220A	DB93-09220A	ASSY CONNECTOR WIRE-FAN OUT	1
23	DB93-09990A	DB93-09990A	DB93-09990A	DB93-09990A	DB93-09990A	DB93-09990A	DB93-09990A	DB93-09990A	DB93-09990A	ASSY CONNECTOR WIRE-POWER	1
24	DB93-13688C	DB93-13688C	DB93-13688C	DB93-13688C	DB93-13688C	DB93-13688C	DB93-13688C	DB93-13688C	DB93-13688C	ASSY CONNECTOR WIRE-DC SIGNAL	1
25	DB96-21678A	DB96-21678B	DB96-21678B	DB96-21678B	DB96-21678C	DB96-21678C	DB96-21678C	DB96-21678D	DB96-21678D	ASSY TUBE EEV-IN	1
26	DB65-00324B	DB65-00324B	DB65-00324B	DB65-00324B	DB65-00324B	DB65-00324B	DB65-00324B	DB65-00324B	DB65-00324B	TERMINAL BLOCK-THERMAL FUSE	1
27	DB81-04295A	DB81-04295A	DB81-04295A	DB81-04295A	DB81-04295A	DB81-04295A	DB81-04295A	DB81-04295A	DB81-04295A	A/S-MOTOR WIRE B	1
28	DB81-04296A	DB81-04296A	DB81-04296A	DB81-04296A	DB81-04296A	DB81-04296A	DB81-04296A	DB81-04296A	DB81-04296A	A/S-MOTOR WIRE A	1
29	DB93-14029A	DB93-14029A	DB93-14029A	DB93-14029A	DB93-14029A	DB93-14029A	DB93-14029A	DB93-14029A	DB93-14029A	ASSY CONNECTOR WIRE-DC SIGNAL	1
30	DB93-16092A	DB93-16092A	DB93-16092A	DB93-16092A	DB93-16092A	DB93-16092A	DB93-16092A	DB93-16092A	DB93-16092A	ASSY CONNECTOR WIRE-AC SIGNAL	1
31	DB95-05011F	DB95-05011F	DB95-05011F	DB95-05011F	DB95-05011F	DB95-05011F	DB95-05011F	DB95-05011F	DB95-05011F	ASSY THERMISTOR IN	1
32	DB92-02793A	DB92-02793A	DB92-02793A	DB92-02793A	DB92-02793A	DB92-02793A	DB92-02793A	DB92-02793A	DB92-02793A	ASSY FUNCTION	1
33	DB93-12483A	DB93-12483A	DB93-12483A	DB93-12483A	DB93-12483A	DB93-12483A	DB93-12483A	DB93-12483A	DB93-12483A	ASSY PCB SUB-EEPROM	1