


■ AR24HSFSJWKXCV



Parts List

NO.	Parts Code	Parts Description	Quantity	Service
			AR24HSFSJWKXCV	
1	DB90-07229G	ASSY-CABI TOP COVER	1	SA
2	DB90-07346B	ASSY CABI BACK-LF	1	SA
3	DB90-02321F	ASSY BRACKET MOTOR	1	SA
4	DB31-00611C	MOTOR FAN	1	SA
5	DB67-00861A	FAN-PROPELLER	1	SA
6	DB96-11197A	ASSY COND UNIT-BENDING	1	SA
6-1	DB96-11196A	ASSY COND OUT	1	SC
6-2	DB90-04211D	ASSY-PLATE COND	3	SNA
7	DB97-02066C	ASSY ACCESSORY	1	SA
7-1	DB73-20134A	RUBBER-LEG	4	SA
7-2	DB67-20011A	DRAIN-PLUG OUT	1	SA
8	DB61-05652A	BAR-STEEL A	1	SA
9	DB61-05653A	BAR-STEEL B	1	SA
10	DB96-17531A	ASSY-4WAY VALVE	1	SA
10-1	DB62-02342A	VALVE SERVICE-SPINDLE	1	SA
10-2	DB97-02689A	ASSY-SOLENOID VALVE	1	SA
10-3	DB62-02283A	VALVE SERVICE-SPINDLE	1	SA
11	DB96-18498A	ASSY TUBE EEV	1	SA
11-1	DB62-11205A	VALVE-COIL EXPAN	1	SNA
11-2	DB62-04267A	VALVE EXPAN	1	SA
12	DB94-03568A	ASSY PARTITION-S501	1	SA
13	DB90-07251D	ASSY CABI FRONT-LF	1	SA
13-1	DB63-03314A	GUARD-FAN	1	SA
14	DB90-07228D	ASSY CABI FRONT-RH	1	SA
15	DB90-07110A	ASSY BRACKET-VALVE	1	SA
16	DB90-07117C	ASSY BRACKET-WIRE PAINT	1	SA
17	DB93-09771H	ASSY CONTROL OUT	1	SNA
17-1	DB93-12326E	ASSY PCB MAIN	1	SA
17-2	DB93-11110A	ASSY PCB SUB-EMI	1	SA
17-3	DB93-11370C	ASSY PCB AUTO	1	SNA
18	DB90-07208G	ASSY CABI BACK-RH	1	SA
19	DB93-13198B	ASSY CONNECTOR WIRE-COMP	1	SA
20	DB95-05071B	ASSY THERMISTOR OUT	1	SA
21	DB63-02297A	GROMMET ISOLATOR	3	SA
22	UG8T300FUBJU	-	1	-
23	DB90-07214L	ASSY BASE OUT-TOTAL	1	SA
24	DB65-00061H	TERMINAL BLOCK	1	SA
25	DB93-13118A	ASSY CONNECTOR WIRE-POWER(EMI TO MAIN)	1	SA
26	DB63-02280A	COVER TERMINAL	1	SA